





印製耳型10大程序 Ten Procedures for Taking Ear Impressions


- 

1. 耳窺鏡檢查
Otosopic Examination
- 


2. 將棉球放入耳內保護耳朵
Insert otoblock into the ears
- 

3. 預備高質素矽膠印模材料
Prepare the high quality silicone impression material
- 


4. 將印耳型材料混合
Mix the ear impression material
- 

5. 印耳型時將口部張開
Open mouth widely when impression material is being injected into the ear
- 

6. 口部保持張開約五分鐘
Do not close mouth until the impression material has completely cured
- 

7. 將耳型輕輕取出
Take out the impression gently
- 

8. 檢查耳型是否完整無缺
Check the impression to make sure it is complete
- 

9. 耳窺鏡檢查，確保耳道清潔
Do otosopic examination again to ensure ear canal free of impression material
- 

10. 將耳型存放在盒內
Store the impression into a box